# PanaCast 50
Screen Mount

Install below screen

Install above screen

# Screen Mount horizontal section

Screen Mount vertical section

Screws

M6x30
(4pcs)

M6x40
(4pcs)

M6x50
(4pcs)

M8x30
(4pcs)

M8x40
(4pcs)

M8x50
(4pcs)

M5x8
(2pcs)

M5x12
(2pcs)

Spacers

2mm
(2pcs)

5mm
(4pcs)

12mm
(2pcs)

22mm
(4pcs)

32mm
(4pcs)

Washers

M6
(4pcs)

M8
(4pcs)

Protective pads

(2pcs)

Tools needed (not supplied in the pack)

phillips head
screwdriver

4mm hex key

**1** If the screen is already wall mounted, remove it from the wall.

**2** Detach the existing **VESA mount** from your screen.

**3** Measure the distance between the VESA mount hole and the bottom of the screen. This distance is **X**.

4 Assemble the Screen Mount and ensure the distance illustrated is approx **X +10cm or X +4 inches**.

**X +10cm or X +4 inches**

5 Screw the horizontal and vertical sections together using the supplied **M5x8 screws** and a **4mm hex key**.

M5x8 ✓

M5x12 ✗

**6** Stick the adhesive **protective pads** to the back of the Screen Mount.

180°

**7** Select the screws, washers and spacers that best fit the contours of your screen.

Screws

M6x30
(4pcs)

M6x40
(4pcs)

M6x50
(4pcs)

M8x30
(4pcs)

M8x40
(4pcs)

M8x50
(4pcs)

Spacers

2mm
(2pcs)

5mm
(4pcs)

12mm
(2pcs)

22mm
(4pcs)

32mm
(4pcs)

Washers

M6
(4pcs)

M8
(4pcs)

8 Screw the Screen Mount and the VESA mount (not supplied) to the screen as illustrated, using the ideal spacer length for the uppermost screws.

Screen

Screen

Bottom of Screen

**9** Tilt the hinge on the PanaCast 50 for easy access to the screen holes.


10 Mount the PanaCast 50 to the Screen Mount using the supplied **M5x12 screws** and a **4mm hex key**.


M5x12

11 Rotate the PanaCast 50 into its final position and angle the camera to point at eye-level.

**1** If the screen is already wall mounted, remove it from the wall.

**2** Detach the existing **VESA mount** from your screen.

**3** Measure the distance between the VESA mount hole and the top of the screen. This distance is **X**.

X

**4** Assemble the Screen Mount and ensure the distance illustrated is approx **X +10cm or X +4 inches**.

**X +10cm or X +4 inches**

5 Screw the horizontal and vertical sections together using the supplied **M5x8 screws** and a **4mm hex key**.

M5x8 ✓

M5x12 ✗

**6** Stick the adhesive **protective pads** to the back of the Screen Mount.

180°

**7** Select the screws, washers and spacers that best fit the contours of your screen.

Screws

M6x30
(4pcs)

M6x40
(4pcs)

M6x50
(4pcs)

M8x30
(4pcs)

M8x40
(4pcs)

M8x50
(4pcs)

Spacers

2mm
(2pcs)

5mm
(4pcs)

12mm
(2pcs)

22mm
(4pcs)

32mm
(4pcs)

Washers

M6
(4pcs)

M8
(4pcs)

8 Screw the Screen Mount and the VESA mount (not supplied) to the screen as illustrated, using the ideal spacer length for the uppermost screws.

Screen

Screen

Top of Screen

9 Tilt the hinge on the PanaCast 50 for easy access to the screw holes.

10 Mount the PanaCast 50 to the Screen Mount using the supplied **M5x12 screws** and a **4mm hex key**.

M5x12

11 Rotate the PanaCast 50 into its final position and angle the camera to point at eye-level.